

CHARGERS



breneco



www.breneco.com

Intelligent Charger



360 112 008

Input:	AC220-240V 50/60Hz	Display:	LCD
Output:	Max. DC6V 2A / DC12V 2A,8A	Battery Type:	WET, MF, CAL, AGM, GEL
Rated Input Current:	0.85Amp	charging stages:	9 step charging stages:
Starting Voltage:	2V	Working Temp :	-20°C to +45°C

Intelligent Charger



360 101 008

Input:	220-240V, 50Hz	Charging Stages:	9 Step
Charging Mode:	12V 4A, 12V Winter 4A, 12V 8A, 12V Winter 8A, 12V LFP 8A, 6V 4A	Display:	LCD
Battery Types:	Lead-Acid and LiFePO4 Batteries	Safety Protection:	Over Voltage, Low Voltage, Overheat, Reverse Polarity Short Circuit,

Jump Starter



360 301 008

Battery Capacity:	8,000mAh	Type-C Input:	5V/2A
Starting Current:	300A@9V	USB Output:	2 pcs 5V/3A, 9V/2A, 12V/1.5A
Peak Current:	600A	Display:	LED
Battery Type:	Lithium Ion Polymer	LED Light:	Steady/Flash/SOS
Battery Cell:	4		

Jump Starter



360 302 010

Battery Capacity:	10,000mAh	Type-C Input:	5V 2A
Starting Current:	400A@9V	USB Output:	2 pcs 5V/3A, 9V/2A, 12V/1.5A
Peak Current:	800A	Display:	LCD
Battery Type:	Lithium Ion Polymer	LED Light:	Steady / Flash SOS
Battery Cell:	4		
Wireless Charge:	10W		

Smart Charger Maintenance



360 412 012

Voltage:	12V	Battery Cap.:	25-300Ah
Charge Rate:	12V-2A/4A/8A/12A	Short Circuit Protection:	Yes
Start Stop:	Yes	Polarity Protection:	Yes
Suitable For:	Lead Acid, Gel, Calcium, EFB, AGM and LiFePO4	Overcharging Protection:	Yes
		LED Indicator:	Yes

Automatic Charger



360 212 012

Input:	AC220-240V 50/60Hz	Insulation	IP20
Output:	6V/2A, 12V/2A, 15A, 15A Li	Class:	
Starting Current:	75A@7.0V	Protection for Use:	Over-charge, Over-heat, Short-circuit, Reverse Polarity
Peak Current:	150A		
Battery Types:	STD, AGM, GEL		

